

EVT Transmission Installation Instructions

Right side bracket.

Take 2 - 3/4" spacers for front and rear of plate, and place between transmission and bracket. Use 20x100mm bolts with washers for mounting to tractor. Lube washers and tighten to 300 ft lbs. See below on next page.

Loosely bolt longer bottom block onto bracket prior to mounting.





Left side bracket.

Take 1 - 1/4" spacer for front and rear of plate, and place between transmission and bracket. Use 20x65mm bolts with washers for mounting to tractor. Lube washers and tighten to 300 ft lbs. See picture on next page.

